

# CAME Copy Manual

Here is the way of copy

## **Step 1: Clear the history code from duplicator**

- 1: Press button A and B continuously until LED flash 3 times
2. Release button B (Keep pressing button A), and press button B Slowly for 3 times, LED flash
3. Release button "A", finish code clearance.

## **Step 2, Copy code from original transmitter**

- 1 Put duplicator aside of original transmitter, as close as possible.
- 2 Press and hold button A of original transmitter, then press and hold button A of duplicator until you see the duplicator's LED flash
- 3 Release both buttons, finish code copy, copy other button in same way.

Button A= Lock button    Button B=unlock button