

SwitchBot Remote

User Manual




Please read this user manual carefully before using your device.

Package Contents




List of Components





Getting Started

1. Download the SwitchBot app via the Apple App Store or Google Play Store.
2. Open our app and register a SwitchBot account or sign in directly if you already have one.




3. Open the battery cover, remove the plastic battery isolation tab, and you will see the indicator light start flashing.




Placement


- Option 1: Place it on a table.



- Option 2: Put it into the Remote holder. Peel off the tape liner on the back of the holder, stick it to a smooth surface and press it for 30 seconds to ensure it is firmly attached. Then put your Remote into the holder.



- Option 3: Add a lanyard to your Remote through the strap-hole for portable use. You may need to purchase a lanyard separately.



- Option 4: Draw pictures or write notes on the DIY stickers provided and then stick them to your Remote for personalized uses.

Pairing Remote

You can pair your Remote with SwitchBot devices like a Bot or a Curtain to control them.

- How to pair a Remote:
1. When pairing, place your phone, Remote and the target device close to each other.
 2. Open the SwitchBot app, tap the Remote card on the home page, tap the Key icon below Key Settings, then your phone will start to scan nearby available devices. Select your target device and set Remote actions for it.

Mapping Keys

The two keys on your Remote can be set individually to trigger actions of two different devices. One key can only trigger one action. For example, you can set the action of the concave key as closing/opening your Curtain, and the convex key as turning on/off your Bot.

Low Battery

When you see a red battery icon appear on the Remote card on the app home page, you may need to replace the battery.

Resetting Factory Settings

Press and hold both keys, and you will see the indicator light starts flashing. Hold the keys for 15 seconds and release when the light stops flashing. Then your Remote will emit a beep sound and the indicator light will light up for 1.5 seconds. Now your remote has been reset to factory settings.

Note: Since all previous settings of your remote will be deleted after resetting, you will need to pair your Remote again.

Specifications

Model: W0301700

Color: White

Material: ABS plastic with UV-resistant coating

Size: 37.1 × 43.1 × 13.4 mm (1.5 × 1.7 × 0.5 in.)

Weight (with battery): 17.7 g (0.6 oz.)

Battery: CR2450

Network Connectivity: Bluetooth Low Energy

Warranty

We warrant to the original owner of the product that the product will be free from defects in materials and workmanship. Please note that this limited warranty does not cover:

1. Products submitted beyond the original limited warranty period.
2. Products on which repairs or modifying have been attempted.
3. Products subjected to falls, extreme temperatures, water, or other operating conditions outside the product specifications.
4. Damage due to natural disaster (including but not limited to lightning, flood, tornado, earthquake, or hurricane, etc.).
5. Damage due to misuse, abuse, negligence or casualty (e.g. fire).
6. Other damage that is not attributable to defects in the manufacture of product materials.
7. Products purchased from unauthorized resellers.
8. Consumable parts (including but not limited to batteries).
9. Natural wear of the product.

Contact & Support

Setup and Troubleshooting:

support.switch-bot.com

Support Email:

support@wondertechlabs.com

Feedback: If you have any concerns or problems when using our products, please send feedback via our app through the Profile > Feedback page.

CE/UKCA Warning

RF exposure information: The EIRP power of the device at maximal case is below the exempt condition, 20 mW specified in EN 62479: 2010. RF exposure assessment has been performed to prove that this unit will not generate the harmful EM emission above the reference level as specified in EC Council Recommendation(1999/519/EC).

CE DOC

Hereby, Woan Technology (Shenzhen) Co., Ltd.

declares that the radio equipment type W0301700

is in compliance with Directive 2014/53/EU. The full

text of the EU declaration of conformity is available

at the following internet address:

support.switch-bot.com

UKCA DOC

Hereby, Woan Technology (Shenzhen) Co., Ltd.

declares that the radio equipment type W0301700

is in compliance with UK Radio Equipment

Regulations (SI 2017/1206). The full text of the UK

declaration of conformity is available at the

following internet address:

support.switch-bot.com

This product can be used in EU member states

and UK

Manufacturer: Woan Technology (Shenzhen) Co., Ltd.

Address: Room 1101, Qiancheng Commercial Center,

No. 5 Haicheng Road, Mabu Community, Xixiang Subdistrict, Bao'an District, Shenzhen, Guangdong, P.R.China, 518100

Wi-Fi: 2412 MHz to 2472 MHz (16.22 dBm)

Operation temperature: -20 °C to 60 °C

FCC Warning

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference

received, including interference that may cause

undesired operation.

NOTE: This equipment has been tested and found

to comply with the limits for a Class B digital device,

pursuant to part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against

harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference

will not occur in a particular installation. If this

equipment does cause harmful interference to radio

or television reception, which can be determined

by turning the equipment off and on, the user is

encouraged to try to correct the interference by

one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the

equipment and receiver.

- Connect the equipment into an outlet on a circuit

different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV

technician for help.

NOTE: The manufacturer is not responsible for any

radio or TV interference caused by unauthorized

modifications to this equipment. Such modifications

could void the user's authority to operate the

equipment.

FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC Warning

This device contains license-exempt transmitter(s)/

receiver(s) that comply with Innovation, Science and

Economic Development Canada's license-exempt

RSS(s). Operation is subject to the following two

conditions:

(1) This device may not cause interference.

(2) This device must accept any interference,

including interference that may cause undesired

operation of the device. L'émetteur/récepteur

exempt de licence contenu dans le présent appareil est conforme aux. CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions

suivantes :

(1) L'appareil ne doit pas produire de brouillage.

(2) L'appareil doit accepter tout brouillage

radioélectrique subi, même si le brouillage est

susceptible d'en compromettre le fonctionnement.

IC Radiation Exposure Statement

This equipment complies with the limits of exposure

to IC radiation defined for an uncontrolled

environment. Cet équipement est conforme aux

limites d'exposition aux radiations de la IC

définies pour un environnement non contrôlé.

KCC Warning

상호: Woan Technology (Shenzhen) Co., Ltd.

기자재 명칭: 리모콘 버튼

모델명: W0301700

제조년월: 2022년 3월

제조사 및 제조국가: Woan Technology (Shenzhen)

Co., Ltd./중국

R-R-Woa-W0301701

NCC Warning

取得審驗證明之低功率射頻器材, 非經核准, 公司、商號

或使用者均不得擅自變更頻率、加大功率或變更原設計

之特性及功能。

低功率射頻器材之使用不得影響飛航安全及干擾合法

通信; 經發現有干擾現象時, 應立即停用, 並改善至無干

擾時方得繼續使用。

前述合法通信, 指依電信管理法規定作業之無線電通信。

低功率射頻器材須忍受合法通信或工業、科學及醫療用

電波輻射性電機設備之干擾。